

## ASM Power Panel



Breaker panel with E-stop function for IFF Hoists.

### Model Range

Code		Enclosure H x W x D	
FF3960Y001	breaker panel for 1 hoist	500x400x250	19.7"x15.8"x 9.8"
FF3960Y002	breaker panel for 2 hoists	700x500x250	27.6"x19.7"x9.8"
FF3960Y003	breaker panel for 3 hoists	700x500x250	27.6"x19.7"x9.8"
FF3960Y004	breaker panel for 4 hoists	700x500x250	27.6"x19.7"x9.8"
FF3960Y006	breaker panel for 6 hoists	700x500x250	27.6"x19.7"x9.8"
FF3960Y007	breaker panel for 7 hoists	700x500x250	27.6"x19.7"x9.8"
FF3960Y008	breaker panel for 8 hoists	700x500x250	27.6"x19.7"x9.8"
FF3960Y010	breaker panel for 10 hoists	900x500x250	35.4"x19.7"x9.8"
FF3960Y012	breaker panel for 12 hoists	900x500x250	35.4"x19.7"x9.8"

### Technical Features

#### Electrical connection

Voltage                    220VAC 3-phase + GRD                    208VAC 3phase + GRD

#### Controls

Main switch

Start push bottom

One power on/off indicator lamp per phase

Emergency stop push button

#### Sub-distribution

3-phase breaker for each motor line

24V transformer for E-stop circuit & 130V transformer for SM power supply

