

FF3670



Alignment connector

Two steel plates to connect rails end to end. Hardware included
Not suitable for moving rails.



material: steel



finish: white zinc plated



weight: 0,294 kg
0,648 lb




volume: 0,0004 cu m
0,0141 cu ft



max. load: NA





weight: 0,300 kg
0,661 lb




scale 1:3

APPLICATIONS



JUNCTION OF TWO FIXED STRAIGHT OR CURVED RAILS

Place one alignment connector on each side of the rail junction. Make sure that the two center holes of the alignment connector line up with the existing holes in the rails. Use the enclosed bolts to assemble the joint. Line up the rails properly before drilling 2 additional holes (Ø 7mm 2/8). Use the two remaining bolts to secure the joint.



IMPORTANT: Don't place the alignment connectors in the lower section of the rail where the carriages run.

IMPORTANT: Use always a support bracket at a rail junction (fig. 1).